







Remy**REMY AUTOMOTIVE EUROPE****REMAN**

DRT0170

Remanufactured unit**With core surcharge****Starter 12V 4kW**

	DRT0170	IVECO	
		i	
		Voltage:	24 V
		Kilowatt:	4 kW
		Rotation:	CW
		Teeth:	10 T
		Tech. Bulletin:	
	SOL 10 		
		A: 89 B: 230 C: 52	

Application:**IVECO: Eurocargo****Cross references:****BOSCH: 0001231016 - IVECO: 42498718, 4892338 ******Remy Automotive Distributor:****Remy**Free online catalogue www.remyinc.eu

**OE numbers shown for reference purposes only

Technical data: 24V/4 kW

X-reference	DRT0170
0001231016	BOSCH
42498718	IVECO
4892338	IVECO

CLASS	EDR	APPL_ID	BRAND	MODEL	VERSION	ENGINE	KW	HP	LITER	DF	DT
STARTER	DRT0170	CV07011	IVECO	EuroCargo	tector 65 E 13	F4AE0481D/F4AE0481D/F4AE0481D	95 - 0	130 - 0	0	200009	
STARTER	DRT0170	CV07012	IVECO	EuroCargo	65 E 15 tector	F4AE0481C/F4AE0481C/F4AE0481C	110 - 0	149 - 0	0	200009	
STARTER	DRT0170	CV07013	IVECO	EuroCargo	65 E15	F4AE0481C	110 - 0	149 - 0	0	200009	
STARTER	DRT0170	CV07014	IVECO	EuroCargo	75 E 13 tector	F4AE0481D/F4AE0481D/F4AE0481D	95 - 0	130 - 0	0	200009	
STARTER	DRT0170	CV07015	IVECO	EuroCargo	75 E 15 tector	F4AE0481C/F4AE0481C/F4AE0481C	110 - 0	149 - 0	0	200009	
STARTER	DRT0170	CV07016	IVECO	EuroCargo	75 E 17, 75 E 18 tector	F4AE0481A/F4AE0481A/F4AE0481A	125 - 130	170 - 177	0	200009	
STARTER	DRT0170	CV07017	IVECO	EuroCargo	75 E 17 K, 75 E 18 K tector	F4AE0481A	125 - 130	170 - 177	0	200009	
STARTER	DRT0170	CV07018	IVECO	EuroCargo	75 E 18 K tector	F4AE0681E	134 - 0	181 - 0	0	200009	
STARTER	DRT0170	CV07019	IVECO	EuroCargo	75 E 15 K tector	F4AE0481C	110 - 0	149 - 0	0	200009	
STARTER	DRT0170	CV07020	IVECO	EuroCargo	90 E 17, 90 E 17D tector, 90 E 17 DP tector, 90 E 18 tector	F4AE0481A/F4AE0481A	125 - 130	170 - 177	0	200009	
STARTER	DRT0170	CV07021	IVECO	EuroCargo	90 E 18 tector, 90 E 18 D tector, 90 E 18 DP tector	F4AE0681E/F4AE0681E/F4AE0681E/F	130 - 134	177 - 182	0	200009	
STARTER	DRT0170	CV07022	IVECO	EuroCargo	90 E 21, 90 E 21 D tector, 90 E 21 DP tector, 90 E 22 tector	F4AE0681D/F4AE0681D/F4AE0681D/F	154 - 160	209 - 218	0	200009	
STARTER	DRT0170	CV07023	IVECO	EuroCargo	90 E 17 K tector, 90 E 17 DK tector	F4AE0481A	125 - 0	170 - 0	0	200009	
STARTER	DRT0170	CV07024	IVECO	EuroCargo	90 E 18 K tector, 90 E 18 DK tector	F4AE0681E	134 - 0	181 - 0	0	200009	
STARTER	DRT0170	CV07025	IVECO	EuroCargo	90 E 21 K tector, 90 E 21 DK tector	F4AE0681D	154 - 0	209 - 0	0	200009	
STARTER	DRT0170	CV07026	IVECO	EuroCargo	140 E 18 W tector	F4AE0681E	134 - 0	181 - 0	0	200009	
STARTER	DRT0170	CV07027	IVECO	EuroCargo	140 E 21 W tector	F4AE0681B	176 - 0	240 - 0	0	200009	
STARTER	DRT0170	CV07028	IVECO	EuroCargo	75 E 18 tector	F4AE0681E/F4AE0681E/F4AE0681E	134 - 0	181 - 0	0	200009	
STARTER	DRT0170	CV07031	IVECO	EuroCargo	100 E 17, 100 E 17 DP tector, 100 E 18 tector	F4AE0481A/F4AE0481A/F4AE0481A	125 - 130	170 - 177	0	200009	
STARTER	DRT0170	CV07032	IVECO	EuroCargo	100 E 18 tector	F4AE0681E/F4AE0681E/F4AE0681E/F	134 - 0	181 - 0	0	200009	
STARTER	DRT0170	CV07033	IVECO	EuroCargo	100 E 21, 100 E 21 DP tector, 100 E 22 tector	F4AE0681D/F4AE0681D/F4AE0681D/F	154 - 160	209 - 217	0	200009	
STARTER	DRT0170	CV07034	IVECO	EuroCargo	100 E 17 K tector, 100 E 17 DK tector	F4AE0481A	125 - 0	170 - 0	0	200009	
STARTER	DRT0170	CV07035	IVECO	EuroCargo	100 E 18 K tector, 100 E 18 DK tector	F4AE0681E	134 - 0	181 - 0	0	200009	
STARTER	DRT0170	CV07036	IVECO	EuroCargo	100 E 21 K tector, 100 E 21 DK tector	F4AE0681D	154 - 0	209 - 0	0	200009	
STARTER	DRT0170	CV07037	IVECO	EuroCargo	100 E 18 W tector, 100 E 18 WS tector	F4AE0681E	134 - 0	181 - 0	0	200009	
STARTER	DRT0170	CV07038	IVECO	EuroCargo	100 E 21 W tector	F4AE0681D	154 - 0	209 - 0	0	200009	
STARTER	DRT0170	CV07050	IVECO	EuroCargo	80 E 17, 80 E 17 D tector, 80 E 17 DP tector, 80 E 18 tector	F4AE0481A/F4AE0481A/F4AE0481A	125 - 130	170 - 177	0	200009	
STARTER	DRT0170	CV07051	IVECO	EuroCargo	80 E 18 tector, 80 E 18 D tector, 80 E 18 DP tector	F4AE0681E/F4AE0681E/F4AE0681E/F	134 - 0	181 - 0	0	200009	
STARTER	DRT0170	CV07052	IVECO	EuroCargo	80 E 21, 80 E 21 D tector, 80 E 21 DP tector, 80 E 22 tector	F4AE0681D/F4AE0681D/F4AE0681D/F	154 - 160	209 - 218	0	200009	
STARTER	DRT0170	CV07053	IVECO	EuroCargo	80 EL 15 tector	F4AE0481C/F4AE0481C	110 - 0	149 - 0	0	200009	

CLASS	EDR	APPL_ID	BRAND	MODEL	VERSION	ENGINE	KW	HP	LITER	DF	DT
STARTER	DRT0170	CV07054	IVECO	EuroCargo	80 E 17 K, 80 E 17 DK tector, 80 E 18 K tector	F4AE0481A	125 - 130	170 - 177	0	200009	
STARTER	DRT0170	CV07055	IVECO	EuroCargo	80 E 18 K tector, 80 E 18 DK tector	F4AE0681E	134 - 0	181 - 0	0	200009	
STARTER	DRT0170	CV07056	IVECO	EuroCargo	80 E 21 K, 80 E 21 DK tector, 80 E 22 K tector	F4AE0681D	154 - 160	209 - 218	0	200009	
STARTER	DRT0170	CV07057	IVECO	EuroCargo	120 E 18 K tector, 120 E 18 DK tector	F4AE0681E	134 - 0	181 - 0	0	200009	
STARTER	DRT0170	CV07058	IVECO	EuroCargo	120 E 24 K tector, 120 E 24 DK tector	F4AE0681B	176 - 0	240 - 0	0	200009	
STARTER	DRT0170	CV07059	IVECO	EuroCargo	120 E28 K tector	F4AE0681A	202 - 205	275 - 279	0	200009	
STARTER	DRT0170	CV07060	IVECO	EuroCargo	120 E 18 tector, 120 E 18 D tector, 120 E 18 DP tector	F4AE0681E/F4AE0681E/F4AE0681E/F	134 - 0	181 - 0	0	200009	
STARTER	DRT0170	CV07061	IVECO	EuroCargo	120 E 24, 120 E 24 DP tector, 120 E 25	F4AE0681B/F4AE0681B/F4AE0681B/F	176 - 185	240 - 252	0	200009	
STARTER	DRT0170	CV07062	IVECO	EuroCargo	120 E 28 tector	F4AE0681A/F4AE0681A/F4AE0681A/F	202 - 205	275 - 279	0	200009	
STARTER	DRT0170	CV07063	IVECO	EuroCargo	130 E 18 tector, 130 E 18 D tector, 130 E 18 DP tector	F4AE0681E/F4AE0681E/F4AE0681E/F	134 - 0	181 - 0	0	200009	
STARTER	DRT0170	CV07064	IVECO	EuroCargo	130 E 24 tector, 130 E 24 D tector, 130 E 24 DP tector	F4AE0681B/F4AE0681B/F4AE0681B/F	176 - 0	240 - 0	0	200009	
STARTER	DRT0170	CV07065	IVECO	EuroCargo	130 E 28 tector	F4AE0681A/F4AE0681A/F4AE0681A/F	202 - 0	275 - 0	0	200009	
STARTER	DRT0170	CV07066	IVECO	EuroCargo	130 E 18 K tector, 130 E 18 DK tector	F4AE0681E	134 - 0	181 - 0	0	200009	
STARTER	DRT0170	CV07068	IVECO	EuroCargo	130 E 24 K tector, 180 E 24 DK tector	F4AE0681B	176 - 0	240 - 0	0	200009	
STARTER	DRT0170	CV07069	IVECO	EuroCargo	130 E 28 K tector	F4AE0681A	202 - 0	275 - 0	0	200009	
STARTER	DRT0170	CV07080	IVECO	EuroCargo	150 E 18 tector	F4AE0681E/F4AE0681E/F4AE0681E	134 - 0	181 - 0	0	200009	
STARTER	DRT0170	CV07081	IVECO	EuroCargo	150 E 24, 150 E 25 tector	F4AE0681B/F4AE0681B/F4AE0681B/F	176 - 185	240 - 252	0	200009	
STARTER	DRT0170	CV07082	IVECO	EuroCargo	150 E 28 tector	F4AE0681A/F4AE0681A/F4AE0681A/F	202 - 205	275 - 279	0	200009	
STARTER	DRT0170	CV07083	IVECO	EuroCargo	150 E 18 K tector	F4AE0681E	134 - 0	181 - 0	0	200009	
STARTER	DRT0170	CV07084	IVECO	EuroCargo	150 E 24 K tector	F4AE0681B	176 - 0	240 - 0	0	200009	
STARTER	DRT0170	CV07087	IVECO	EuroCargo	150 E 28 K tector	F4AE0681A	202 - 205	275 - 279	0	200009	
STARTER	DRT0170	CV07094	IVECO	EuroCargo	180 E 21 tector	F4AE0681D/F4AE0681D/F4AE0681D	154 - 0	209 - 0	0	200009	
STARTER	DRT0170	CV07095	IVECO	EuroCargo	180 E 24, 180 E 25 tector	F4AE0681B/F4AE0681B/F4AE0681B	176 - 185	240 - 251	0	200009	
STARTER	DRT0170	CV07098	IVECO	EuroCargo	180 E 28 tector	F4AE0681A/F4AE0681A/F4AE0681A	202 - 0	275 - 0	0	200009	
STARTER	DRT0170	CV07101	IVECO	EuroCargo	180 E 21 K tector	F4AE0681D	154 - 0	209 - 0	0	200009	
STARTER	DRT0170	CV07102	IVECO	EuroCargo	180 E 24 K tector	F4AE0681B	176 - 0	240 - 0	0	200009	
STARTER	DRT0170	CV07103	IVECO	EuroCargo	180 E 28 K tector	F4AE0681A	202 - 205	275 - 279	0	200009	
STARTER	DRT0170	CV07104	IVECO	EuroCargo	320 E 28 T tector	F4AE0681A/F4AE0681A/F4AE0681A	202 - 0	275 - 0	0	200009	
STARTER	DRT0170	CV08252	IVECO	EuroCargo	120 EL 17, 120 EL 17 P tector, 120 E 18, 120 EL 18 tector	F4AE0481A	125 - 134	170 - 182	0	200009	
STARTER	DRT0170	CV08253	IVECO	EuroCargo	120 EL 21, 120 EL 21 P tector, 120 E 22, 120 EL 22 tector	F4AE0681D	154 - 160	209 - 217	0	200009	